

GIGA T PRO II

Wireless Timer Remote Control



Available for major DSLR camera brands

Features & Benefits

For Canon

Part No: 1000 750.0
EAN: 5099113007506

For Nikon

Part No: 1000 751.0
EAN: 5099113007513

For Sony

Part No: 1000 752.0
EAN: 5099113007520

For Olympus Panasonic

Part No: 1000 759.0
EAN: 5099113007599

- Perfect for time-lapse photography, cloudscapes, landscapes, wildlife shots & more
- Features include self-timer, interval timer, long exposure setting and exposure count settings
- Through-wall transmission
- 100m range
- Reliable FSK 2.4GHz frequency available worldwide
- LCD display with back lighting
- Channel selector for individual control of multiple cameras
- Can also be used as a short cable shutter release to eliminate camera shake



Transmitter



Receiver



QR Code Technology

A QR Code on each product pack, directs the user to LIVE, online and up to date compatibility information for each brand.







Characteristics

Repeat Mode for Interval Shooting

- The two graphics below help to illustrate the timed sequences.
- The basic programme (A) below allows you to set up a timed shooting sequence, defining the delay, the number shots, the interval shots and so on.
- For example you may wish to take 5 shots, 1 minute apart, and delay this sequence by an hour.
- The 'repeat mode for interval shooting' (B) allows you to repeat the above sequence (A) every 4 hours for up to 99 repeats.



Interchangeable connectors for different camera models



Model	Part No.	Camera	Range	Wireless	Cable
Giga T Pro II Wireless Remote Control for Canon DSLR	1000 750.0	EOS 1200D/ EOS 1000D / EOS 100D / EOS 1100D / EOS 1D / EOS 1D C 4K D/ EOS 1D Mark II / EOS 1D Mark IV/ EOS 1DS / EOS 1DS Mark II / EOS 1DS Mark III / EOS 1DX / EOS 20D/ EOS 300D/ EOS 30D/ EOS 350D/ EOS 350D / EOS 400D/ EOS 40D/ EOS 450D / EOS 500D / EOS 50D / EOS 550D / EOS 5D/ EOS 5D MARK II/ EOS 5D MARK III/ EOS 600D/ EOS 60D / EOS 60Da / EOS 650D / EOS 6D / EOS 700D / EOS 70D / EOS 7D/ EOS-1D Mark II N/ EOS-1Ds MARK III / G15/ SX50 HS/ 1D/ G5x Pentax: D/ K-5 II / K-5 IIs / K-5 / K-50 / K-500 / K-7 / K100D / K100D/ K10D / K200D/ K20D / K50/ K500 Samsung: GX-10/ GX-1L / GX-1S / GX-20	Up to 100m	✓	✓
Giga T Pro II Wireless Remote Control for Nikon DSLR	1000 751.0	P7700/ P7800/ D1/ D100/ D200/ D2H/ D2HS/ D2X/ D2Xs / D3/ D300/ D300S/ D3100/ D3200/ D3300/ D3S/ D3x/ D4/ D5000/ D5500/ D5100/ D5200/ D5300/ D600/ D610/ D70/ D700/ D7000/ D70s/ D70s/ D7100/ D80/ D800/ D800E/ D90/ D1 (H)/ D1 (X)/ Df/ D7200	Up to 100m	✓	✓
Giga T Pro II Wireless Remote Control for Sony DSLR	1000 752.0	A77/ A350/ A100/ A200/ A300/ A450/ A500 / A550/ A700/ A850/ A900/ A560/ A580/ A33/ A55/ A35 / A37/ A57/ A65/ A99/ A7s/ A58/ A77 II/ A3000/ A5000/ A6000/ HX400/ RX100II/ RX100III / A7s Mk II/ RX100 IV	Up to 100m	✓	✓
Giga T Pro II Wireless Remote Control for Olympus / Panasonic DSLR	1000 759.0	Olympus: C-5060/ C-8080/ E-1 / E-10/ E-100/ E-20/ E-3/ E-30/ E-300/ E-400 / E-410/ E-410/ E-450/ E-5/ E-510/ E-520/ E-550/ E-600 / E-620/ E-PL2/ E-PL5/ E-PM2/ E420/ OM-D E-M10/ OM-D E-M5/ Pen E-P1/ PEN E-P3 / PEN E-P5 / SP-510 UZ/ SP-550 UZ/ SP-560 UZ/ SP-565 UZ/ SP-570 UZ/ SP-590UZ/ XZ-1 (MID)/ XZ-2 IHS Panasonic: DMC-FZ100/ DMC-FZ150/ DMC-FZ20/ DMC-FZ30/ DMC-FZ50/ DMC-FZ60/ DMC-G1/ DMC-G10/ DMC-G2/ DMC-G3/ DMC-G5/ DMC-GF1/ DMC-GH4 /DMC-GH1/ DMC-GH3/ DMC-L1/ DMZ-FZ200/ DMC-G6/ DMC-G7/ DMC-G70/ DMC-FZ300/ DMC-FZ330	Up to 100m	✓	✓

