



www.hahnel.ie

REMOTE SHUTTER RELEASE



Remote Controls

Eliminate camera shake with the
hähnel Remote Shutter Release



Available for major DSLR camera brands

Features & Benefits

- Autofocus, Bulb Function and Continuous Shooting functions
- Reduce Camera Shake
- Supplied with interchangeable camera connectors for all DSLR's of one brand
- 2m extension cable included, giving the choice of 0.8m shutter release or a 2.8m cable length
- Twist & lock cable system for a secure connection

For Canon

Part No: 1000 720.0
EAN: 5099113007209

For Nikon

Part No: 1000 721.0
EAN: 5099113007216

For Sony

Part No: 1000 723.0
EAN: 5099113007230

For Olympus Panasonic

Part No: 1000 726.0
EAN: 5099113007261



Best Value
PhotoPlus



QR Code Technology

A QR Code on each product pack, directs the user to LIVE, online and up to date compatibility information for each brand.



hähnel
quality accessories



Characteristics

Remote Shutter Connectors



Twist & Lock Connectors



Model	Part No.	Camera	Range	Wireless	Cable
HRC 280 Remote Shutter Release for Canon DSLR	1000 720.0	Canon: EOS 1200D/ EOS 1100D / EOS 1000D/ EOS 700D/ EOS 650D/ EOS 600D/ EOS 550D/ EOS 500D/ EOS 450D/ EOS 400D/ EOS 350D/ EOS 300D/ EOS 100D/ EOS 70D/ EOS 60D/ EOS 50D/ EOS 40D/ EOS 30D/ EOS 20D/ EOS 20Ds/ EOS 10D/ EOS 7D/ EOS 6D/ EOS 5D/ EOS 5D Mark II/ EOS 5D Mark III/ EOS 1D/ EOS 1DX/ EOS 1DC/ EOS 1DS Mark II/ EOS 1DS Mark III/ EOS 1DS Mark IV/ SX50HS/ G10/ G11/ G12/ G15/ G1X/ G1X Mk II/ Rebel T1i/ T2i/ G5x Pentax: K-5 II/ K-5 IIS/ K-5/ K-7/ K10/ K20/ K50/ K100/ K200/ K500 Samsung: GX10/ GX20	0.8m or 2.8m	✓	✓
HRC 280 Remote Shutter Release for Nikon DSLR	1000 721.0	P7700/ P7800/ D7100/ D7000/ D5300/ D5200/ D5100/ D5000/ D5500/ D3300/ D3200/ D3100/ D610/ D600/ D700/ D800/ D800E/ D300/ D300s/ D200/ D100 (when attached to Nikon MB-D100 battery grip) / D3 /D3X/ D3S/ D4/ D4S/ D2X/ D2XS/ D2H/ D2HS/ D1 / D1X/ D1H/ D80/ D70s/ D90/ Df/ D7200	0.8m or 2.8m	✓	✓
HRC 280 Remote Shutter Release for Sony DSLR	1000 723.0	A350/ A100/ A200/ A300/ A450/ A500/ A550/ A700/ A850/ A900/ A560/ A580/ A99/ A77/ A65/ A57/ A55/ A37/ A35/ A33 / HX50/50V / HX60/60V HX300 / HX400/400V RX100M2/M3 /A7/A7R A58K/A58Y / A3000 A6000 / NEX-3NL/3NY	0.8m or 2.8m	✓	✓
HROP 280 Remote Shutter Release for Olympus / Panasonic DSLRv	1000 726.0	Olympus: C-5060 / C-8080/ E-1/ E-10/ E-100/ E-20/ E-3/ E-30/ E-300/ E-400 / E-410/ E-450/ E-5/ E-510/ E-520/ E-550/ E-600/ E-620/ E-PL2/ E-PL5/ E-PM2 / E420/ OM-D E-M10/ OM-D E-M5/ Pen E-P1/ PEN E-P3/ PEN E-P5/ SP-510 UZ/ SP-550 UZ/ SP-560 UZ/ SP-565 UZ/ SP-570 UZ/ SP-590UZ/ XZ-1 (MID)/ XZ-2 IHS Panasonic: DMC-FZ100/ DMC-FZ150/ DMC-FZ20/ DMC-FZ30/ DMC-FZ50/ DMC-FZ60/ DMC-G1/ DMC-G10/ DMC-G2/ DMC-G3/ DMC-G5/ DMC-GF1/ DMC-GH1/ DMC-GH3/ DMC-GH4/ DMC-L1/ DMZ-FZ200/ DMC-G6/ GX7/ GX1/ GH2/ LC1/ DMC-G7/ DMC-G70	0.8m or 2.8m	✓	✓

